



HOW TO INSTALL HANGER BOLTS (1/2" WRENCH NEEDED)

- 1- THREAD THE 2 SUPPLIED 1/2" NUTS ONTO THE MACHINE SIDE OF THE HANGER BOLT AND TIGHTEN AGAINST EACH OTHER AS SHOWN
- 2- USE 1/2" WRENCH AND TIGHTEN HANGER BOLT INTO THE PRE DRILLED HOLES USING A SLIGHT DOWNWARD PRESSURE IN A CLOCKWISE DIRECTION

3- TIGHTEN INTO HOLE LEAVING 1 1/2" STICKING UP.

4- REMOVE BOTH NUTS FROM BOLT ALL 4 SHOULD LOOK LIKE THIS WHEN FINISHED.

5) 5/16" BOLTS AND 2 1/2" NUTS PROVIDED IN KIT.

PEDISTAL SHOWN WITH ADDITIONAL 24" ROUND DISK

ADDITIONAL 24" ROUND DISK PART # 01932410-1 SOLD SEPARATELY

Designs of distinction
by Brown Wood, Inc.
est. 1998

REVISION HISTORY		
REV	REV DATE	DESCRIPTION
A	6-5-2017	CHANGED MID SECTION TO 21. ALL OTHER PARTS MATCH TABLE HEIGHT PEDISTAL

TOLERANCES	
WIDTH	± .03125"
THICKNESS	± .03125"
LENGTH	± .0625"
ANGULAR	± x.x°
PROFILE	± x.xxx"
Use General Tolerances Unless Noted	

MATERIALS AND FINISHES	
PLEASE VISIT OUR WEBSITE FOR A COMPLETE LIST. www.brownwoodinc.com 1-800-328-5858	
NOTES: ADDITIONAL SPECIES AVAILABLE	
Do not scale. Use dimensions only. All dimensions are in inches unless noted	

TITLE: 33.5" CHARLESTON PEDISTAL	
NOMINAL SIZE 12" X 12" X 33.5"	
DWG #: 01290280-1	REV:
DATE: 6/22/2017	SCALE: 1:12