

Mounting Bun Feet to Frame or Frameless Cabinetry

What you need:



2" x 2" Mounting Plates



M5-08 x 10MM Pan Head Screw



5/16" Threaded Inserts



5/16" Hangar Bolts



M5 Tee Nut

How to:



We would love to add your work to our gallery and social media. To be featured, email photos to rjacobs@brownwoodinc.com.

Designs of Distinction[®] by Brown Wood, Inc.
7040 Lawndale Ave. Lincolnwood, IL 60712
800.328.5858
www.brownwoodinc.com

Follow us and share your photos!
[@dodbybrownwood](https://www.instagram.com/dodbybrownwood)

